


TV-TABLE ASSEMBLY INSTRUCTION



IMPORTANT: Surfaces must be cleaned with a solution of a smooth soap and water, then cleared with a dry towel. Do not use solvents over surfaces or structural tubes.


MODEL TV-3037








Thanks for purchasing one of our products, please read carefully the assembly instructions before the installation (Attention: Do not tighten the screws until all screws are in place).



MODEL TV-3037





PART	QTY.	ITEM		PART	QTY.	ITEM	
A	18	6X40 MM		E	4	6X35 MM	
B	4	4X30 MM		F	6		
C	8	3X15 MM			1		
D	8	6X25 MM					

6x40mm bolt installation as below:

